

Core Lab audio system for crossovers

Amp should be set to **AUX**.

Plug audio jack from amp into *audio-technica* receiver. The port is on the bottom labelled **monitor out**.

The receiver is capable of receiving two mic transmissions. To turn the receiver on, slide the top **EXT-OFF-1-BOTH** to the right one click for one transceiver or two clicks to the right for two transceivers.

To turn on the 'mics' (*audio-technica* transmitter), press the top **power/mute** button until the unit comes on.

The receiver and transmitters will stay on the shelf under the table-top to protect them from getting damaged.

At the end-of-the-Expedition they will be returned to the Imaging Office.

Click [here](#) for link to the User Manual.

Archive Version

- [Core Lab Audio System 378S 2020-02-23](#)